

To change console settings from 2500 to 3500

1. Simultaneously press and hold Quick Start and Clear 3 seconds.
2. Press Enter when you see any prompt up until 'Transmission.'
3. Press up/down to make your selection.

Transmission 1 = HLT2500 and HLT3000 style

Transmission 2 = HLT3500 style

4. Press Enter. Keep pressing Enter.
5. Pull the batteries and put them back in if you just keep looping.

The LCB settings can be changed from 2500 to 3500 by changing the pot value from 3.5 (3500) to 5 (2500). "zero setting" is all the way counter clockwise