


SPIRIT FITNESS ENTERTAINMENT (ENT) CONSOLE

CONSOLE WI-FI / ETHERNET SET-UP

Quick Setup Instructions for All 800 & 900 ENT Products


STEP 1

From the Home Screen, tap the **Home key** text 10 times to take you to **Settings**




STEP 2

From Settings, touch the **Maintenance key** to take you to the **Maintenance** screen





STEP 3

From the Maintenance screen, touch the **Wi-Fi/Ethernet Setup** key to take you to the **Wi-Fi Setup** screen



STEP 4

If you are going to **use Wi-Fi**, follow step 4. If you are going to use Ethernet, skip to step 5.





- a.) Touch **Wi-Fi key** to get into **Wi-Fi Setting**
- b.) Touch **On key** to turn on Wi-Fi
- c.) Touch **Scan key** to scan for networks
- d.) Select the desired network

- e.) Enter password, if secure network
- f.) If network does not appear, you can press **Scan key** or **Add Network key** and manually add a network

STEP 5

For Ethernet set-up, touch **Ethernet key** (make sure Ethernet cable is plugged into machine from router)



- a.) Touch **Ethernet Configuration key**
- b.) Select **DHCP** to search for connection or static IP to enter manually

STEP 6

Once you have completed Step 4 or Step 5, touch the **Home key** in the upper left corner. Next press **Internet key** to verify you have connection.

