

Cybex 770T/790T Touch Screen Calibration

To access menu do one of the following:

CYBEX LOGO Press and hold Cybex logo for 6 seconds to access Screen Lock and Toolbox.

LANGUAGE ICON Press and hold language logo for 6 seconds to access Screen Lock and Toolbox.

1. Tap the Access Toolbox icon to display the Access to Toolbox login screen.



2. Enter the sequence:

3. Tap the Setup icon to display the Setup menu.

4. Tap the A/V Config icon to display the A/V configuration options.

Touch Calibration Tap Cybex GO monitor in nine locations to calibrate screen.

Exit Diagnostics by tapping the Toolbox icon, then tap the Home icon . The screen will refresh.