

TECHNICAL TRAINING – DIAGNOSTICS JOB AID 2017

CONSUMER UNITS (HOME)

Console Series & Model (LCD size & LED color)	Product	Diagnostics Access	Optional Settings / Managers Menu Access	Service Menu & Manufacturer Menu Access	Navigation Buttons	TR Immobilized Option	TR Striding Belt Tensioning Tape Distance
		When Life Fitness attract screen is running 1. P [WORKOUTS] quick jump button 1x 2. Press the top corners of the touchscreen in the following sequence: Left-Right-Left-Right.	1. Same as "Diagnostics Access" Procedure 2. P [CONFIGURATION] 1x 3. P [MANAGER] 1x	Discover Manufacturer Access: 1. Tap the software version. 2. keypad pops up 3. enter 919	Use Buttons in Touch Screen		A: 98.4cm (38 1/2 inch) B: 99.1cm (39 inch) C: 98.9cm (38 15/16 inch)
Platinum Club Inspire & Engage (7 inch & 15 inch LCD) 	TR CT LC	1. P [SELECT WORKOUT] 1x 2. P [<i>Life Fitness</i>] 3x slowly	1. Same as "Diagnostics Access" Procedure 2. P [CONFIGURATION] 1x 3. P [MANAGER] 1x	<u>Service Menu:</u> Same as Diagnostics Access Section <u>Manufacturer Menu:</u> 1. Same as "Diagnostics Access" Procedure 2. P [CONFIGURATION] 1x 3. P [MANUFACTURER] 1x 4. P [R] [D] [R] [D]	Use Buttons in Touch Screen	Step 1: P [STOP] 3x Step 2: P [SPEED ▼] 3x	A: 98.4cm (38 1/2 inch) B: 99.1cm (39 inch) C: 98.9cm (38 15/16 inch)
Platinum Achieve Console (Amber LED) 	TR CT LC	1. P & H [COOL DOWN] + P [CLEAR] 2x 2. R [COOL DOWN] when <CODE VER...> appears	1. Same as "Diagnostics Access" Procedure 2. P [ENTER] 1x	<u>Service Menu:</u> 1. Same as Diagnostics Access 2. P & H [COOL DOWN] + P [ENTER] 1x <u>Manufacturer Menu:</u> 1. Same as "Diagnostics Access" Procedure 2. P & H [COOL DOWN] + P & H [QUICK START] + P [ENTER] 1x or Manufacturer Menu: 1. See Diagnostics Access 2. P & H [COOL DOWN] + P & H [POWER] + P [ENTER] 1x	[ENTER] = Forward [CLEAR] = Backwards [▲] and [▼] = Change Setting	Step 1: P [STOP] 3x Step 2: P [SPEED ▼] 3x Not Applicable	A: 98.4cm (38 1/2 inch) B: 99.1cm (39 inch) C: 98.9cm (38 15/16 inch)
Integrity & Club Series (Amber LED) 	TR	1. Option B: P & H [PAUSE] + P [CLEAR] 2x 2. Option C: P & H [PAUSE] + P [STOP] 1x	1. Same as "Diagnostics Access" Procedure 2. S to <CONFIGURATION> 3. P [ENTER] 1x 4. S to <MANAGER CONFIG> 5. P [ENTER] 1x	<u>Service Menu:</u> (See Diagnostics Access Section) <u>Manufacturer Menu:</u> 1. See Diagnostics Access 2. S to <CONFIGURATION> 3. P [ENTER] 1x 4. S to <MANUFACTURER CONFIG> 5. P & H [PAUSE] + P [ENTER] 1x	[ENTER] = into Submenu [CLEAR] = Back from Submenu [Time ▲] or [Time ▼] = Scroll through Menu's / Change Setting [Incline ▲] or [Incline ▼] = Scroll through Menu's / Change Setting [Speed ▲] or [Speed ▼] = Scroll through Menu's / Change Setting [PAUSE] = Auto Scroll Lock	P & H [SPEED ▼] + P [PAUSE] 1x	A: 98.4 cm (38 1/2 inch) B: 99.1 cm (39 inch) C: 98.9 cm (38 15/16 inch) NON lubricated belt: A: 127 cm (50 inch) B: 127.6 cm (50 1/4 inch) PRE lubricated belt: A: 97.8 cm (38 1/2 inch) B: 98.4 cm (38 3/4 inch)
T5-0 (Amber LED) 	TR	1. P [STOP] 2x 2. P & H [WALK]	1. P & H [START/ENTER] for 3+ Seconds until <MY TREAD USERS> appears	<u>Service Menu:</u> (See Diagnostics Access Section) <u>Manufacturer Menu:</u> 1. See Diagnostics Access 2. S to <CONFIGURATION> 3. P [ENTER] 1x 4. S to <MANUFACTURER CONFIG> 5. P & H [JOG] + P [START/ENTER] 1x	[ENTER] = move forward [STOP] = backwards or press repeatedly to save and exit diagnostics [POWER SWITCH] = turn off to save and exit diagnostics [ENTER] = make selection Console [ARROW ▲] or [ARROW ▼] = Scroll through Menu's / Change Setting [POWER SWITCH] = turn off to save and exit diagnostics [PAUSE/CLEAR] = Back or Exit	P & H [SPEED ▼] + P [STOP] 1x	A: 127 cm (50 inch) B: 127.6 cm (50 1/4 inch)
T5-5 & T7-0 (Amber LED) 	TR	1. P [CLEAR] 2x 2. P & H [JOG] on Active Zone 3. P [9] [1] [9] P [START/ENTER]			[ENTER] = make selection [ARROW ▲] or [ARROW ▼] = scroll through Menu's [ARROW ▲] or [ARROW ▼] = change parameter value [RESET] = exit	P & H [SPEED ▼] + P [STOP] 1x	A: 127 cm (50 inch) B (T5-5): 127.6 cm (50 1/4 inch) B (T7-0): 128 cm (50.37 inch)
F1 or Smart (Blue LCD) 	TR	1. After powering up or after P [RESET] 2. <PLEASE WAIT> appears. 3. P & H [PAUSE/RESUME] on the activity zone until <DIAGNOSTICS> appears 4. P [ENTER]	1. P [SETTINGS] 1x	Not Applicable			A: 93.5 cm (25 inch) B: 93.8 cm (25.12 inch)
Basic Consumer Workouts (Blue LCD) 	TR CT LC	1. P [RESET] 3x 2. When <PLEASE WAIT> disappears P & H [ENTER]	1. When <USE **> appears P & H [ENTER] for 5 Seconds	<u>Service Menu:</u> (See Diagnostics Access Section)	[←] and [→] = Scroll through Menu's [▲] or [▼] = Change Setting [ENTER] = Save	P & H [▼] + P [ENTER]	A: 97.8 cm (38 1/2 inch) B: 98.4 cm (38 3/4 inch)
Advanced & Go Consumer Workouts (Blue LCD) 	TR						