
















Console Series & Model (LCD size / LED color)	Product	Diagnostics Access	Optional Settings / Managers Menu Access	Service Menu & Manufacturer Menu Access	Navigation Buttons	TR Immobilized Option	TR Striding Belt Tensioning Tape Distance
Discover SE & SI Console (10, 16 & 19 inch LCD) 	TR CT LC	When Life Fitness attract screen is running 1. P [WORKOUTS] quick jump button 1x 2. Press the top corners of the touchscreen in the following sequence: Left-Right-Left-Right. 	1. Same as "Diagnostics Access" Procedure 2. P [CONFIGURATION] 1x 3. P [MANAGER] 1x	Discover Manufacturer Access: 1. Tap the software version, 2. keypad pops up, 3. enter 919	Use Buttons in Touch Screen		A: 98.4cm (38 7/8 inch) B: 99.1cm (39 inch) C: 98.9cm (38 15/16 inch)
Engage & Inspire Console Elevation (17 inch & 15 inch LCD) 	TR CT LC	1. P [SELECT WORKOUT] 1x 2. P [Life Fitness] 3x slowly	1. Same as "Diagnostics Access" Procedure 2. P [CONFIGURATION] 1x 3. P [MANAGER] 1x	Service Menu: Same as Diagnostics Access Section Manufacturer Menu: 1. Same as "Diagnostics Access" Procedure 2. P [CONFIGURATION] 1x 3. P [MANUFACTURER] 1x 4. P [9] [1] [9] [OK]	Use Buttons in Touch Screen	Step 1: P [STOP] 3x Step 2: P [SPEED ▼] 3x	A: 98.4cm (38 7/8 inch) B: 99.1cm (39 inch) C: 98.9cm (38 15/16 inch)
Next Generation 2 LCD (12 inch LCD) 	TR CT LC <i>Silver</i>	1. P Touch Screen 1x 2. P & H [COOL DOWN] P [] 2x	2. P [CONFIGURATION] 1x 3. P [MANAGER] 1x	1. Same as "Diagnostics Access" Procedure 2. P [CONFIGURATION] 1x 3. P [MANUFACTURER] 1x 4. P [9] [1] [9] [OK]	Use Buttons in Touch Screen	Step 1: P [SPEED ▼] 1x for 1 Sec. Step 2: P [PAUSE] 1x	NON lubricated belt: A: 127 cm (50 inch) B: 127.6 cm (50 1/4 inch) PRE lubricated belt: A: 97.8 cm (38 1/2 inch) B: 98.4 cm (38 3/4 inch)
Achieve Console Elevation (Amber LED) 	TR CT LC	1. P & H [COOL DOWN] + P [CLEAR] 2x 2. R [COOL DOWN] when <CODE VER...> appears	1. Same as "Diagnostics Access" Procedure 2. P [ENTER] 1x	Service Menu: 1. Same as Diagnostic Access 2. P & H [COOL DOWN] + P [ENTER] 1x Manufacturer Menu: 1. Same as "Diagnostics Access" 2. P & H [COOL DOWN] + P & H [QUICK START] + P [ENTER] 1x Service Menu: 1. See Diagnostics Access 2. P & H [COOL DOWN] + P [ENTER] 1x Manufacturer Menu: 1. See Diagnostic Access 2. P & H [COOL DOWN] + P & H [POWER] + P [ENTER] 1x	[ENTER] = Forward [CLEAR] = Backwards [▲] and [▼] = Change Setting	Step 1: P [STOP] 3x Step 2: P [SPEED ▼] 3x Not Applicable	A: 98.4 cm (38 7/8 inch) B: 99.1 cm (39 inch) C: 98.9 cm (38 15/16 inch)
Integrity & Club Series (Amber LED) 	TR	1. Option a: P & H [PAUSE] + P [CLEAR] 2x 1. Option b: P & H [PAUSE] + P [STOP] 1x	1. Same as "Diagnostics Access" Procedure 2. ⬅ to <CONFIGURATION> 3. P [ENTER] 1x 4. ⬅ to <MANAGER CONFIG> 5. P [ENTER] 1x	Service Menu: (See Diagnostics Access Section) Manufacturer Menu: 1. See Diagnostics Access 2. ⬅ to <CONFIGURATION> 3. P [ENTER] 1x 4. ⬅ to <MANUFACTURER CONFIG> 5. P & H [PAUSE] + P [ENTER] 1x	[ENTER] = Into Submenu [CLEAR] = Back from Submenu [Time ▲] or [Time ▼] = Scroll through Menu's / Change Setting [Incline ▲] or [Incline ▼] = Scroll through Menu's / Change Setting [Speed ▲] or [Speed ▼] = Scroll through Menu's / Change Setting [PAUSE] = Auto Scroll Lock	P & H [SPEED ▼] + P [PAUSE] 1x	A: 98.4 cm (38 7/8 inch) B: 99.1 cm (39 inch) C: 98.9 cm (38 15/16 inch) NON lubricated belt: A: 127 cm (50 inch) B: 127.6 cm (50 1/4 inch) PRE lubricated belt: A: 97.8 cm (38 1/2 inch) B: 98.4 cm (38 3/4 inch)
Next Gen. Next Gen. 2 Classic (Silver / Red LED) 	TR	1. Option c: P & H [PAUSE] + turn (on/off switch) ON 2. H [PAUSE] when <SERVICE> appears	1. Same as "Diagnostics Access" Procedure 2. ⬅ to <CONFIGURATION STATE> 3. P [ENTER] 1x 4. ⬅ to <MANAGER CONFIG> 5. P [ENTER] 1x	Service Menu: 1. Same as "Diagnostics Access" Procedure 2. ⬅ to <MAINTENANCE STATE> 3. P [ENTER] 1x Manufacturer Menu: 1. See Diagnostics Access 2. ⬅ to <CONFIGURATION STATE> 3. P [ENTER] 1x 4. ⬅ to <MANUFACTURERS CONFIG> 5. P & H [PAUSE] + P & H [COOLDOWN] + P [ENTER] 1x	[ENTER] = Into Submenu [CLEAR] = Back from Submenu [▲] or [▼] = Scroll through Menu's / Change Setting	P & H [SPEED ▼] + P [PAUSE] 1x	A: 97.8 cm (38 1/2 inch) B: 98.4 cm (38 3/4 inch) C: 98.9 cm (38 15/16 inch)
Activate Series Treadmill (Amber LED) 	TR	1. P [CLEAR] 2x to reset system 2. after reset immediately P & H [PAUSE] until <SERVICE MENU> appears	1. Same as "Diagnostics Access" procedure 2. ⬅ to <CONFIGURATION STATE> 3. P [ENTER] 1x 4. ⬅ to <MANAGER CONFIG> 5. P [ENTER] 1x	Service Menu: (See Diagnostics Access Section) Manufacturer Menu: 1. See Diagnostics Access Section 2. P & H [▼] + P & H [QUICK START] + P [ENTER] 1x	[ENTER] = Into Submenu [CLEAR] = Back from Submenu [▲] or [▼] = Scroll through Menu's / Change Setting	P & H [SPEED ▼] + P [PAUSE] 1x	A: 97.8 cm (38 1/2 inch) B: 98.4 cm (38 3/4 inch) C: 98.9 cm (38 15/16 inch)
Activate Series (Amber LED) 	CT LC	1. P & H [▲ green key] + P [CLEAR] 2x 2. R [▲ green key] when <CODE VER...> appears	1. Same as "Diagnostics Access" procedure 2. P & H [COOL DOWN] + P [ENTER] 1x	Service Menu: (See Diagnostics Access Section) Manufacturer Menu: 1. See Diagnostics Access Section 2. P & H [▼] + P & H [QUICK START] + P [ENTER] 1x	[ENTER] = Into Submenu [CLEAR] = Back from Submenu [▲] or [▼] = Scroll through Menu's / Change Setting	Not Applicable	Not Applicable
Lifecycle GX (Blue LCD) 	LC GX	To enter user mode: 1. P [] 1x (less then 2 seconds !)	1. P & H [] + P & H [] for 3 seconds	Not Applicable	[▲] or [▼] = Scroll through Menu's / Change Setting [OK] = select	Not Applicable	Not Applicable
iPTV Elevation Engage (15 inch LCD) 	TR CT LC	1. P [SELECT WORKOUT] 1x 2. P [Life Fitness] 3x slowly 3. Select [CONFIGURATION SETTINGS] 4. Select [MEDIA CENTER] 5. Select [TV SET UP]	Not Applicable	Not Applicable	[▲] or [▼] = Scroll through Menu's / Change Setting [OK] = select	Not Applicable	Not Applicable